

PRODUCT USAGE CHECKLIST



3M™ GLASS CLEANER | 50586

- Streak-free shine
- Non drip foaming action - clings to vertical surfaces
- Safe for tinted and non-tinted windows
- Safe to use on plastic, chrome and metal

DIRECTIONS FOR USE:

Shake container well before using.

A

Spray a liberal amount of cleaner onto surface holding the can 8-12 inches from the surface. Allow product to foam up for a few seconds.

B

Wipe dry with a 3M™ Microfibre Detail Cloth (PN 39016) or a soft cloth or paper towel. Buff with a clean area of the cloth for a brilliant shine.

Available at:



3M Select.co.uk
The Official 3M
UK Online Store

www.3M.co.uk/carcare

A P P E A R A N C E